


Damson HearBuds

USER GUIDE



FUNCTIONS

Power on/off

The HearBuds will automatically turn on when removed from the charging case. They will also automatically power off when they are placed back in the charging case. To override the auto power on/off, simply press down and hold the control button on the left HearBud. You will hear the voice prompt, "Powering off".

Pairing

Ensure both buds are fully charged. Remove both buds from the charging case and position in ears. You will hear the voice prompt "pairing mode". Ensure the left bud that is marked "L" is placed in the left ear and the bud marked "R" is placed in the right ear. Navigate to your Bluetooth settings on your streaming device and select "HearBuds". You will hear the voice prompt, "Damson headset connected". You can now stream audio from you device.

PLEASE NOTE: pairing is only required once per streaming device. After the first use your HearBuds will automatically connect to the device.

Function buttons

Pause/ Resume audio	Tap once on the button (either bud) to pause. Tap again to resume the audio.
Skip track	Double tap the button (either bud).
Accept a call	Tap once on the button (either bud)
End a call	Tap once on the button (either bud)
Power off	Long press (L bud only)




Multifunction button

CHARGING

Charge the case

To charge the case, insert micro-USB end of the supplied charging cable into the rear of the charging case. Place the USB end of the supplied cable into a USB plug and charge from the mains supply using a DC5V/2A plug.

The LED on the charging case will flash RED when charging. When the charging case is fully charged, it will change to solid RED.



Charge the HearBuds

Place the HearBuds in the charging case. The LED's on the HearBuds will turn RED while charging. When the HearBuds are fully charged, the LEDs will briefly flash BLUE and then go out. The HearBuds can be charged at the same time as the case is charging.



RED
charging



BLUE
fully charged



NOTE: The charging case LED will flash 4 times when it has sufficient power to charge the HeadBuds. When it is low on power and needs recharging the LED will flash once.

REPLACEMENT TIPS

The HearBuds can be used with or without tips. Two sizes of tips are supplied in the box.

RE-CONNECTING YOUR HEARBUDS


Occasionally your HearBuds may lose connection to each other. If this happens follow the steps below to connect them together, which should take no longer than a minute.

1. Delete HearBuds from your smart device in the Bluetooth profile settings.
2. Remove both HearBuds from the charging case and place them in your ear.
3. Press and hold the button until you hear "power off" and let go.
4. Press and hold the button on both HearBuds. You will hear it announce "power on" and "paring mode" and finally 2 sets of descending beeps.

5. Place the HearBuds back into their charging case until the red led turns on.

6. Take them out. The HearBuds will both flash blue a couple of times and then the left HearBud will flash alternatively.

7. Connect to your smart device. Your HearBuds should now be reconnected to each other and your device.



RESET YOUR HEARBUDS

This is the procedure to follow if the Damson HearBuds are both showing in the device's connection.

This is the process to undertake to reset the HearBuds:

1. Ensure the HearBuds are charged.
2. Remove both HearBuds from the charging case.
3. Press and hold the button on both Hearbuds until the LED flashes alternatively red/blue twice and then stop.
4. Return the HearBuds to the charging case. Wait until both LED's are solid red. Remove and pair as normal.

If the previous process doesn't work a factory reset will be necessary:

1. Remove both HearBuds from the charging case.
2. Press and hold the button on both HearBuds until the flash red/blue alternatively.
3. Double press the button on one Hearbud.
4. The HearBuds should now be completely reset and can be paired as normal.

Bluetooth version	v5.0
Protocols	A2DP,AVRCP,HFP,HSP
Frequency range	2.402GHz~2.480GHz ISM Band
Range	Up to 10 metres
Continues playback	Approx. 6 hours
Standby time	Approx. 150 hours
Charge time	1-2 hours
Water Resistance rating	IPX4 – sweat and rain resistant

Frequently asked questions

Q: There are two "HearBuds" listed on my device.

A: Forget both "HearBuds" and repair using the instructions.

Customer support

For customer support numbers and live chat
damsonglobal.com/support